

Doctor Submission Checklist

Follow the instruction as specified below and please call InPronto with any questions.

1

PVS MAXILLARY, MANDIBULAR IMPRESSIONS & BITE REGISTRATION



Do **NOT** use metal trays. Impressions will be scanned in the Cone Bean machine.

Impressions checklist

1. Take impressions with putty first.
2. Remove Interproximal areas with a sharp blade.
3. Take final impression with regular wash material.

Bite Registration checklist

1. Take full arch bite in centric occlusion.
2. Use putty rolled up like a sausage.
3. Do Not use Blue Mouse.

2

DENTAL PHOTO SET



PANORAMIC FILM



FULL MOUTH SERIES



3

CONE BEAN SCAN IN DICOM EXPORTED FORMAT

